



## PREM-RA-RACK1



## PREM-RA-RACK2 \*



- Front door network cable
- Back door network cable
- Kit 1 door's position sensor wired back to input one on Kit 2's POE reader board
- Kit 2 door's position sensor
- Quick connects for the integrated reader, latch and relay

\* Install up to seven RACK2s per one RACK1